


## COMMENT ALLUMER MA TÉLÉVISION ?

Appuyer sur le bouton rouge en haut de la télécommande de votre télévision




## COMMENT ACCÉDER AUX DIFFÉRENTES CHÂÎNES ?

Pointer le curseur sur IPTV et appuyer sur «OK» pour accéder aux différentes chaînes TV



## COMMENT ACCÉDER AUX CHÂÎNES EN LANGUES ÉTRANGÈRES ?


Utiliser la flèche de droite pour sélectionner les chaînes en langues étrangères



## COMMENT DUPLIQUER L'ÉCRAN DE MON SMARTPHONE SUR MA TV (MIRRORING) ?

ETAPE 1 : Se connecter au réseau WIFI de Terre Blanche


ETAPE 2 : Mettre le curseur sur «mirroring» et appuyer sur «OK»



ETAPE 3 : Choisir le système d'exploitation de votre appareil (Apple ou Android)


ETAPE 4 : Suivre les instructions à l'écran de votre télévision

[RETOUR AUX GUIDES](#)




## HOW TO TURN ON MY TV?

Press on the red button situated on the top of the remote control



## HOW TO NAVIGATE THROUGH THE CHANNEL LIST?

Put the cursor on IPTV, click «OK» and then select the channel you desire



## HOW TO ACCESS TO THE FOREIGN CHANNELS?


Use the right cursor on your remote control to select the foreign channel desired



## HOW TO MIRROR YOUR DEVICE'S SCREEN?

STEP 1 : Log on Terre Blanche's WIFI.

STEP 2 : Put the cursor on «mirroring» then press «OK» on your remote control



STEP 3 : Choose the operating system of your device (Apple or Android)

STEP 4 : Follow the instruction on your screen's TV

[BACK TO THE USER GUIDES](#)